



Micro-Head Spectral-Interference
Laser Displacement Meter
SI-F1000 Series



World's first $\varnothing 2$ mm ($\varnothing 0.08$ ") micro-head



$\varnothing 2$ mm ($\varnothing 0.08$ ")

Ultra High-accuracy
Reliable Measurement


A new type of laser displacement meter for even greater accuracy.

KEYENCE technology defies expectations.

Introducing the world's first micro-head, with the highest measurement accuracy in its class and a level of performance that was previously thought impossible. Several advanced technologies combine for a new type of laser displacement meter.



Principle of measurement





Spectroscopic unit

Controller
SI-F1003V

Thickness measurement type
SI-F80

Long-distance type
SI-F10

Micro-head type
SI-F01

Micro-head type spectral interference
laser displacement meter
SI-F1000 Series

Ultra High-resolution

RESOLUTION:

0.25 μm (0.000010")

World's Smallest

MICRO-HEAD SIZE:

$\varnothing 2 \text{ mm}$ ($\varnothing 0.08 \text{''}$)

First in the Industry

MEASUREMENT PRINCIPLE:

Spectral interference method

Head variations capable of expanding measurement applications

Micro-Head Type

Best suited for measurements requiring ultra high-accuracy, restricted mounting space, and high temperatures.


SI-F01



HEAD SIZE
ø2 mm / ø0.08"

HEAT RESISTANCE
IP67 85°C/185°F

RESOLUTION
0.25µm/0.000010"



MAJOR TECHNICAL DATA	
Measurement range	0.05 to 1.1 mm 0.002" to 0.04"
Resolution	0.25 µm 0.000010"
Linearity	±0.3 µm ±0.000012"
Head size	ø2 mm ø0.08"


DISTANCE
11.3 mm / 0.44"

RESOLUTION
0.25µm/0.000010"

Long Distance Type

Long-distance measurement with high accuracy.

SI-F10



MAJOR TECHNICAL DATA	
Measurement range	11.3 to 12.35 mm 0.44" to 0.49"
Resolution	0.25 µm 0.000010"
Linearity	±0.3 µm ±0.000012"
Head size	ø8 mm ø0.32"


DISTANCE
80 mm / 3.15"

RESOLUTION
0.25µm/0.000010"

Thickness (Gap) Measurement Type

High accuracy achieved by targeting thickness measurement.

SI-F80



MAJOR TECHNICAL DATA	
Setting distance	80 to 81.1 mm 3.15" to 3.19"
Measurable thickness	0.05 to 1.1 mm 0.002" to 0.04"
Resolution	0.25 µm 0.000010"
Linearity	±0.3 µm ±0.000012"
Head size	ø12 mm ø0.47"

No heat generation and no noise

Advantages of the optical fiber head structure

The measurement head consists of only optical fibers and lenses, with no electronic parts.

Small size, light weight, and heat resistant

These features greatly reduce the constraints on selecting an installation area. A micro-head of this type can be used with a wider range of measurement applications because it can be installed in places where conventional units cannot.

No heat generation

An exothermic body is one of the error-causing factors in high-accuracy measurement. The optical fiber head structure produces no heat generation in the head section.


Not influenced by electromagnetic noise

The measurement head contains no electrical circuits. Because of this, it is not influenced by electromagnetic noise, which is difficult to isolate and remove.

APPLICATION

Measuring wafer thickness

The micro-head can be used to measure the thickness and warpage of high-precision objects such as silicon wafers.



ADVANTAGE

Ultra high-resolution
Resolution of 0.25 μm 0.000010"

Multifunctional controller
The arithmetic operation circuit instantly converts the measurement data to a thickness.

No heat generation
There are no electrical components in the head that generate heat.

Measuring the behavior of rollers in a copy machine

The micro-head can be used to measure the behavior of each component inside precision machines.



ADVANTAGE

$\phi 2$ mm ($\phi 0.08$ ") micro-head
No special location is needed for installation.

Heat resistant to 85°C (185°F)
Measurement is possible even beside an exothermic body.

5-kHz high-speed sampling
Even high-speed targets can be measured securely.

Positioning high-accuracy stages

The micro-head can be used to detect the location at which a stage stops, allowing the difference from the reference value to be fed back to the related equipment.



ADVANTAGE


Setting distance of 10 mm (0.39") or longer
There is no danger of collision.

Up to six-axis simultaneous measurement
Multi-axis control is achieved with no time errors

$\phi 8$ mm ($\phi 0.47$ ") small head
No special location is needed for installation.

Measuring roller run out with high accuracy

The micro-head can be used to measure the run out in rollers, which demand precise measurement, such as in the case of coating rollers.



ADVANTAGE


No damage to workpiece
Non-contact measurement prevents damage to workpieces.

Direct indication of amount of run out
The amount of run out is instantly calculated and displayed by the controller.

5-kHz high-speed sampling
The high-speed rotation of target objects can be followed.

Measuring exposure mask gaps

The micro-head can be used to measure the gap between an exposure mask and glass substrate.



ADVANTAGE


Setting distance of 80 mm (3.15")
The micro-head can be installed even when the mask is thick.

$\phi 12$ mm ($\phi 0.47$ ") small head
No special location is required for installation.

No heat generation
There are no electrical components in the head to generate heat.

Measuring the thickness of glass discs

The micro-head can be used to measure the thickness of optically transparent targets.



ADVANTAGE

Ultra high-resolution
Resolution of 0.25 μm 0.000010"



5-kHz high-speed sampling
The thickness of rapidly rotating targets can be measured.

Up to six-axis simultaneous measurement
Multi-axis control is achieved with no time errors.

Intelligent controller offering convenience and ease of use

Simultaneous control of up to six heads

By connecting expansion controllers to the main controller, up to six heads can be used simultaneously for measurement.



All-head simultaneous measurement


Multiple heads are synchronized to achieve simultaneous measurement. These can be used to make simultaneous measurements at multiple points on a moving object and high-accuracy measurements for an object placed between sensor heads.

Multi-calculation

Measurement values from multiple heads can be instantly calculated. Simple settings enable the controller to perform complex calculations.

Measuring a step height relative to a reference point


The difference in height between each measurement point and the reference point is obtained.



Measurement value 1 = A - B,
Measurement value 2 = A - C,
Measurement value 3 = A - D, ...

Measuring relative differences


Differences in relative distances between specific sensor heads and a target are measured.



Measurement value 1 = A - B,
Measurement value 2 = B - C,
Measurement value 3 = A - C, ...

Measurement of flatness


The difference between the maximum and minimum of all the measured values is obtained.



Measurement value 1 =
MAX (A, B, C, ...) - MIN (A, B, C, ...) ...

Measuring warpage


The warpage at specified measurement points is obtained.



Measurement value 1 = $B - (A + C) / 2$...

Measuring the thicknesses of multiple points


Pairs of heads are used to measure the thicknesses at multiple points.



Measurement value 1 = X - (A + B),
Measurement value 2 = Y - (C + D),
Measurement value 3 = Z - (E + F), ...

Measuring the average height

The average height of the surface is obtained for specified measurement points on the surface.




Measurement value 1 = Ave (A, B, C, ...) ...

Wide array of interfaces


The controller is equipped with six different I/O interfaces that make it possible for the controller to communicate with almost any peripheral device.

USB	Binary output	Ethernet
RS-232C	Analog	Discrete I/O



Separate display/setting panel

Controller design that stresses usability has resulted in a separate display. The display/setting panel may be separated depending on the controller installation. The display section can thus be installed away from the control unit and the controller section can be mounted on a DIN rail in the control panel. When used on a table top, the controller and display section can be combined into a single unit.



When used on a table top
The one-piece display/controller setup saves installation space.



When attached to a control unit
The display can be attached to the front panel and the controller section can be mounted on a DIN rail in the panel.

Displaying the amount of light

The amount of light received by a sensor head can be displayed in 256 levels. Checking the amount of received light helps confirm the measurement stability for individual target objects and reduces the labor-hours needed for angle adjustment during installation.



When the sensor is installed perpendicular to the target:
A large amount of reflected light returns into the sensor.



When the sensor is installed at an angle to the target:
A sufficient amount of reflected light may not be returned to the sensor.

“SI-Navigator 3”, PC software dedicated to ease of use and data collection



Operating environment required to use SI-H13 (SI-Navigator 3)

Item	Minimum system requirements
CPU	Pentium III, 1 GHz or higher (1.7 GHz or higher is recommended)
OS	Windows 10 ¹ Windows 7 (SP1 or later) ² Windows Vista (SP2 or later) ³ Windows XP (SP3 or later) ⁴
Memory capacity	256 MB or higher (1 GB or more is recommended)
Display resolution	1024 x 768 pixels, 24-bit full color or higher
Free hard disk space	1 GB or larger
Interface	One of the following interfaces is required. - USB: Revision 2.0, high-speed (full speed in USB1.1 compatible mode) ⁵ - LAN: 100BASE-TX or 10BASE-T ⁶ - RS-232C (serial port)

The other system requirements must meet those recommended for your OS.

¹ Home, Pro, and Enterprise editions are supported.

² Home Premium, Professional, and Ultimate editions are supported.

³ Ultimate, Business, Home Premium, and Home Basic editions are supported.

⁴ Professional and Home editions are supported.


⁵ Connection through a USB hub is not included in the guarantee.

⁶ Connection to LAN and connection via a router is not included in the guarantee.



Simple configuration

Simply position the cursor to a desired setting menu and make a selection. With many pull-down lists and icons available for selection, anyone can easily configure.



ICON SELECTION

The user can quickly access setting menus that are frequently used, such as the measurement value display, received light waveform display, and data storage menus.

OUT SETTING

Twelve different output channels are supported. There are setting menus offering considerable flexibility, such as tolerance, scaling, and calculation between OUTs.

LIST OF SETTINGS

The list lets the user view all of the settings together.

PROGRAM SWITCHING

Eight programs can be toggled between for even greater flexibility. Settings can be easily copied between programs and initialized.


[Head Settings]		[HEAD01]	[HEAD02]	[HEAD03]
Measurement mode	Mode	Standard	Standard	Standard
LASER CTRL group	LASER CTRL	OFF	OFF	OFF
Mask setting	LASER CTRL 1	OFF	OFF	OFF
Mask boundary	POG-1	---	---	---
	POG-2	---	---	---
ALARM Error	Number of Errors	100	100	100
	Number for recovery	0	0	0
	ALARM Level	32	32	32
[OUT Settings]		[OUT01]	[OUT02]	[OUT03]
Calculation method	Mode	AVE/P-P/MAX	Calculation bet.	OUT
	HEAD	---	---	---
	OUT	---	---	---
	ADD/SUB OUT-A	---	---	---
	ADD/SUB Operator	---	PLUS	---
	ADD/SUB OUT-B	---	---	---
	AVE/P-P/MAX/MIN	OUT01	OFF	---
		OUT02	ON	---
		OUT03	ON	---
		OUT04	ON	---
		OUT05	ON	---
		OUT06	ON	---
		OUT07	ON	---
		OUT08	ON	---

Data Storage

The controller can hold up to 1.2 million points of measurement data, which can then be sent to a PC connected to the controller via the USB interface. Settings can be arbitrarily changed for sampling rates, the number of measurement points, and data collection via external signals.


ANALYSIS WITH SI-NAVIGATOR

SI-Navigator can display waveforms. It lets the user zoom waveforms in/out, as well as overlay them on one another. It also makes it possible to read values simply by positioning a cursor.



ANALYSIS WITH EXCEL


Data collected with SI-Navigator can be saved in CSV format, so it can be read in Excel.



Displaying received light waveforms

The amount of received light can be displayed as a waveform. This serves as a rough indication of the measurement stability. This is very useful when making measurements on workpieces with low reflectance and for checking whether the amount of received light is small because of a tilted measurement head or target.

How the light is being received is displayed as a waveform. The amplitude of the waveform indicates the intensity of received light.




The horizontal position of the waveform peak indicates both the distance to and/or the thickness of the workpiece.

The detection level can be changed arbitrarily with the received light waveform.

Displaying measurement values

Values displayed on the controller can be checked on the PC. Up to 12 OUT values can be displayed simultaneously. This function is useful when many channels are connected or when there are many calculation settings.



Any or all OUT values can be selected.



Sensor head

Type	Micro-head type		Long distance type		Thickness measurement type	
Model	Sensor head	SI-F01	SI-F10		SI-F80	
	Spectrum unit	SI-F01U3	SI-F10U3		SI-F80U3	
Measurement range	0.05 to 1.1 mm 0.002" to 0.04" *1		11.3 to 12.35 mm 0.04" to 0.49" *1		0.05 to 1.1 mm 0.002" to 0.04" *2 (Possible detection distance : 80 to 81.1 mm 3.15" to 3.19")	
Light source	Infrared SLD Central wavelength 820 nm Output 0.6 mW, Class 1 Laser product (IEC60825-1, FDA (CDRH) Part 1040.10 **)					
Beam spot diameter ³	ø20 µm ø0.001"		ø40 µm ø0.002"		ø20 µm ø0.001"	
Linearity	±0.3 µm ±0.000012" **		±0.3 µm ±0.000012" **		±0.3 µm ±0.000012" **	
Resolution	0.25 µm 0.000010" *6		0.25 µm 0.000010" *6		0.25 µm 0.000010" *7	
Sampling cycle	200 µs					
Light source for guide	Red semiconductor laser Wavelength 650 nm Output 0.1 mW, Class 1 Laser product (IEC60825-1, FDA (CDRH) Part 1040.10 **)					
LED display	Target near center of measurement range: green lights. Target within measurement range: orange lights. Target outside measurement range: Flashes orange.					
Temperature fluctuation	Spectrum unit		0.01% of F.S./°C			
Environment resistance	Enclosure rating	Sensor head	IP67		IP64	
	Ambient light	Incandescent lamp or fluorescent lamp: 10000 lux max.				
	Ambient temperature	Sensor head	0 to +85°C 32°F to 185°F		0 to +40°C 32°F to 104°F	
	Relative humidity	Sensor head	0 to +35°C 32°F to 95°F			
		Spectrum unit	35 to 85%RH (No condensation)			
Vibration	Sensor head	10 to 55 Hz, 1.5 mm 0.06" double amplitude in X, Y, and Z directions, 2 hours respectively				
	Spectrum unit	10 to 55 Hz, 0.5 mm 0.02" double amplitude in X, Y, and Z directions, 2 hours respectively				
Material	Sensor head	SUS				
	Spectrum unit	Polycarbonate				
Weight	Sensor head (including cable)	Approx. 24 g		Approx. 38 g		Approx. 39 g
	Spectrum unit	Approx. 1 kg				


*1 Indicates distance from the front of the sensor head. For long distance type sensor heads there is an individual difference of up to ±0.2 mm ±0.01".
 *2 The thickness measurement type sensor head displays the measurement range for the distance between plates of glass. Ensure that the measurement target is within the possible detection distance range.
 *3 Indicates the minimum beam spot diameter within the measurement range.
 *4 This value is obtained when the measurement target is a glass plate with the number of averaging measurements set to 256.
 *5 This value is obtained by measuring the gap between two glass plates with the number of averaging measurements set to 256.
 *6 This value is obtained by measuring a glass plate surface located at the center of the measurement range with the number of averaging measurements set to 4,096.
 *7 This value is obtained by measuring a 0.3 mm 0.01" thick glass target within the possible detection distance with the number of averaging measurements set to 4,096.
 *8 The laser classification for FDA is based on IEC60825-1 in accordance with the requirements of Laser Notice No. 50.

Controller

Designation	Main Controller		Expansion controller**		
Model	Single unit type	SI-F1003V		SI-FA103	
	Separate type**	SI-F1003/SI-FD500			
No. of connectable spectrum units	2		1		
Display	Minimum display unit	0.001 µm		N/A	
	Display range	±999.999 µm to ±9999.99 mm, ±0.04" to ±0.4" (7 settings selectable)			
	Display cycle	10 times/sec.			
Terminal block	Laser remote interlock input	Non-voltage input		N/A	
	TIMING1 input	Non-voltage input 2			
	RESET1 input	Non-voltage input			
	Auto-zero1 input				
	Laser control input				
	Analog voltage output	±10 V × 2 outputs, Output impedance: 100 Ω			±10 V × 1 output, Output impedance: 100 Ω
	Analog current output	4 to 20 mA × 2 outputs, Maximum load resistance: 350 Ω			4 to 20 mA × 1 output, Maximum load resistance: 350 Ω
Alarm output	NPN open-collector output (N.C.)		N/A		
Expansion connector	General comparator output	NPN open-collector output		N/A	
	TIMING input	Non-voltage input 2		N/A	
	RESET input	Non-voltage input			
	Auto-zero input	Non-voltage input × 3 inputs			
	Program switch input				
	Alarm output				NPN open-collector output (N.C.)
	Comparator/binary output	Binary output	Measured value data output (21 bits) OUT selectable NPN open-collector output		
Strobe output		NPN open-collector output			
Binary selection output		NPN open-collector output			
Binary selection input		Non-voltage input			
RS-232C interface	Measured data output and control input/output (Baud rate selectable to 115,200 bps max.)				
USB interface	USB 2.0 high speed compliant (USB 1.1 Full-SPEED compatible)				
Ethernet interface	100Base-TX/10Base-T				
Major functions	12 Out simultaneous measurement calculation, average, filter, scaling measurement, measured value alarm, tolerance setting, auto-zero, data storage, light monitor, 8-program memory, interferometer mode, mask, connection of setting support software, etc.				
Power supply	Power supply voltage	24 VDC ±10% Ripple 10% (P-P) max.		Supplied from the main controller	
	Maximum current consumption	One head connected: 0.6 A or less. Six heads connected: 1.5 A or less.			
Environment resistance	Ambient temperature ³	0 to +50°C 32°F to 122°F			
	Relative humidity	35 to 85%RH (No condensation)			
	Vibration**	10 to 55 Hz, 0.5 mm 0.02" double amplitude in X, Y, and Z directions, 2 hours respectively			
Weight	Approx. 600 g		Approx. 300 g		

*1 Up to four expansion controllers can be connected to the main controller.
 *2 The SI-F1003 can be used independently. The measured value display and setting change can be done with the display panel (SI-FD500) and setup support software (SI-H13).
 *3 When two or more expansion controllers are connected, the ambient temperature is 0 to 40°C 32°F to 104°F.
 *4 When two or more expansion controllers are connected, the vibration resistance is *10 to 55 Hz, 0.3 mm 0.01" double amplitude in X, Y, and Z directions, 2 hours respectively*.
 • NPN open-collector output rating: 50 mA max. (40 V max.), Residual voltage: 0.5 V max.
 • Non-voltage input rating: ON voltage: 1 V max., OFF current: 0.6 mA max.
 • Part of the input/output circuit of the SI-F1000 Series is internally common. Be careful that no potential difference is generated between the internally common terminals due to the potential difference between the cables/external devices. For details, refer to "Precautions on wiring".

System configuration



Components

Sensor head

Micro-head type
SI-F01



Long distance type
SI-F10



Thickness measurement type
SI-F80



Spectrum unit
SI-F01U3/
SI-F10U3/
SI-F80U3



(One spectroscopic unit is needed for each sensor head.)

Optional unit

Head mounting jig (For SI-F01)
OP-84480



Controller

Single unit type
SI-F1003V



Separate type
SI-F1003



Expansion controller
SI-FA103



Back surface

Spectrum unit spacer
OP-84474



(Supplied together with the spectroscopic unit)

Display

Display panel
SI-FD500



Cable

Controller-to-sensor head unit connecting cable

CB-A07/CB-A2/CB-A5/
CB-A10/CB-A20/CB-A30



Controller-to-spectrum unit extension cable

CB-A5E/CB-A10E

Display-to-controller cord
0.33 m 1.08': OP-84428
3 m 9.84': OP-51655
10 m 32.81': OP-51656

Software

Dedicated PC software "SI-Navigator 3"
SI-H13




Dimensions

Sensor head


Micro-head type

SI-F01




Long distance type

SI-F10



Spectrum unit


SI-F01U3/SI-F10U3/SI-F80U3



Controller


Single unit type

SI-F1003V




Expansion controller

SI-FA103




Thickness measurement type

SI-F80



Head mounting jig (For SI-F01)

OP-84480




Display


Unit: mm inch

Display panel

SI-FD500




Panel cutout




Spectrum unit spacer

OP-84474



Separate type

SI-F1003




Additional accessories

Controller-to-sensor head unit connecting cable

CB-A07/CB-A2/CB-A5/CB-A10/

CB-A20/CB-A30



CALL TOLL FREE TO CONTACT YOUR LOCAL OFFICE
1-888-KEYENCE
1-888-539-3623

www.keyence.com

SAFETY INFORMATION
Please read the instruction manual carefully in order to safely operate any KEYENCE product.

CONTACT YOUR NEAREST OFFICE FOR RELEASE STATUS

KEYENCE CORPORATION OF AMERICA

Head Office 500 Park Boulevard, Suite 200, Itasca, IL 60143, U.S.A.

PHONE: +1-201-930-0100 FAX: +1-855-539-0123 E-mail: keyence@keyence.com

AL Birmingham	CA San Jose	CO Denver	IL Chicago	MI Detroit	NJ St. Louis	NC Raleigh	PA Philadelphia	TN Nashville	WI Milwaukee
AR Little Rock	CA Cupertino	FL Tampa	IN Indianapolis	MI Grand Rapids	MO Elmwood Park	OH Cincinnati	PA Pittsburgh	TN Austin	
AZ Phoenix	CA Los Angeles	GA Atlanta	KY Louisville	MN Minneapolis	NY Rochester	OH Cleveland	SC Greenville	TX Dallas	
CA San Francisco	CA Irvine	IA Iowa	MA Boston	MO Kansas City	NC Charlotte	OR Portland	TN Knoxville	WA Seattle	

KEYENCE CANADA INC.

Head Office PHONE: +1-905-366-7655 FAX: +1-905-366-1122 E-mail: keyencecanada@keyence.com
Montreal PHONE: +1-514-694-4740 FAX: +1-514-694-3206 Windsor PHONE: +1-905-366-7655 FAX: +1-905-366-1122

KEYENCE MEXICO S.A. DE C.V.

PHONE: +52-55-8850-0100 FAX: +52-81-8220-9097
E-mail: keyencemexico@keyence.com

The information in this publication is based on KEYENCE's internal research/evaluation at the time of release and is subject to change without notice. Company and product names mentioned in this catalog are either trademarks or registered trademarks of their respective companies. The specifications are expressed in metric units. The English units have been converted from the original metric units. Copyright (c) 2011 KEYENCE CORPORATION. All rights reserved.

KA1-1017

SI_NonECP-KA-C-US 1126-4 611562